






















DESCRIPTION	ADAPTOR	ADAPTOR'S KIT CODE
<p>Front IS Ø 180 mm</p>		<p>FD40062-10</p>
<p>Front IS Ø 200 mm</p>		<p>FD40063-10</p>
<p>Front IS Ø 220 mm Rear IS Ø 200 mm</p>		<p>FD40064-10</p>
<p>Front PM6" Ø 200 mm</p>		<p>FD40065-10</p>
<p>Front Boxxer Ø 200 mm</p>		<p>FD40066-10</p>
<p>Front PM6" Ø 180 mm</p>		<p>FD40074-10</p>
<p>Front FOX40 Ø 200 mm</p>		<p>FD40073-10</p>



<p>Front BOXXER Ø 220 mm</p>		<p>FD40087-10</p>
<p>Front QR20 Ø 180 mm</p>		<p>FD40088-10</p>
<p>Front FOX40 Ø 220 mm</p>		<p>FD40084-10</p>
<p>Front PM6" Ø 220 mm</p>		<p>FD40085-10</p>
<p>Rear IS Ø 220 mm</p>		<p>FD40086-10</p>
<p>Front BOXXER Ø 180 mm</p>		<p>FD40091-10</p>
<p>Front FOX40 Ø 180 mm</p>		<p>FD40092-10</p>

<p>Front IS Ø 160 mm Front FOX40 Ø 203 mm</p>		<p>FD40089-10</p>
<p>Rear IS Ø 203 mm</p>		<p>FD40093-10</p>
<p>Front PM8" Ø 220 mm</p>		<p>FD40106-10</p>
<p>Front PM6" Ø 203 mm</p>		<p>FD40111-10</p>
<p>Rear IS Ø 160 mm</p>		<p>FD40131-10</p>
<p>Rear IS Ø 180 mm</p>		<p>FD40132-10</p>
<p>Front IS Ø 203 mm</p>		<p>FD40134-10</p>